


User Manual

HT104



1. Device



2. How to power On/Off?

The switch on the side of the device is an ON/OFF switch.

3. LED Light Indications

Color	Description	State	Meaning
● Red	System LED	Slow Flashing	Device operating normally
		Fast Flashing	Device operating abnormally
		Off	Device powered off or in Sleep Mode
● Green	Network LED	On	Server linking succeeded
		Flash	Device connecting to network or server
		Off	Device powered off or in Sleep Mode
● Blue	GNSS LED	On	Device fixing normally
		Flash	Device searching GNSS
		Off	Device powered off or in Sleep Mode

Safety Information

This section provides important instructions for safely operating the HT104. Follow these requirements and recommendations carefully to avoid dangerous situations. Read and adhere to all instructions before using the device.



To prevent mechanical damage, transport the device in impact-resistant packaging. Before use, position the device so that the LED indicators are visible. The LED indicators display the device status.



Do not disassemble the device. If the device is damaged, or the power cables are not isolated, or the insulation is damaged, DO NOT touch the device before unplugging the power supply.



Protect the device from water and excessive humidity.



All wireless communication devices may generate interference that could affect nearby electronic devices.



WARNING! Do not install or use the HT104 in a manner that distracts the driver or interferes with vehicle operation.



Installation and/or handling during a lightning storm is prohibited.



Do not dispose of batteries with household waste. Dispose of damaged or depleted batteries at a designated recycling facility or battery collection point.